

Frequency Chart for 310/330 CE Version

LCD Display	Freq (MHz)
CH-01	863.000
CH-02	863.050
CH-03	863.100
CH-04	863.150
CH-05	863.200
CH-06	863.250
CH-07	863.300
CH-08	863.350
CH-09	863.400
CH-10	863.450
CH-11	863.500
CH-12	863.550
CH-13	863.600
CH-14	863.650
CH-15	863.700
CH-16	863.750
CH-17	863.800
CH-18	863.850
CH-19	863.900
CH-20	863.950
CH-21	864.000
CH-22	864.050
CH-23	864.100
CH-24	864.150
CH-25	864.200
CH-26	864.250
CH-27	864.300
CH-28	864.350
CH-29	864.400
CH-30	864.450

LCD Display	Freq (MHz)
CH-31	864.500
CH-32	864.550
CH-33	864.600
CH-34	864.650
CH-35	864.700
CH-36	864.750
CH-37	864.800
CH-38	864.850
CH-39	864.900
CH-40	864.950
CH-41	865.000

Frequency Chart for 310/330 CE Version

LCD Display	Freq (MHz)
CH-01	863.000
CH-02	863.050
CH-03	863.100
CH-04	863.150
CH-05	863.200
CH-06	863.250
CH-07	863.300
CH-08	863.350
CH-09	863.400
CH-10	863.450
CH-11	863.500
CH-12	863.550
CH-13	863.600
CH-14	863.650
CH-15	863.700
CH-16	863.750
CH-17	863.800
CH-18	863.850
CH-19	863.900
CH-20	863.950
CH-21	864.000
CH-22	864.050
CH-23	864.100
CH-24	864.150
CH-25	864.200
CH-26	864.250
CH-27	864.300
CH-28	864.350
CH-29	864.400
CH-30	864.450

LCD Display	Freq (MHz)
CH-31	864.500
CH-32	864.550
CH-33	864.600
CH-34	864.650
CH-35	864.700
CH-36	864.750
CH-37	864.800
CH-38	864.850
CH-39	864.900
CH-40	864.950
CH-41	865.000