



200 Valley Road, Suite 101, Mount Arlington, NJ 07856

Tel: +1.973.810.3070

Fax: +1.973.810.3076

email: sales@azdencorp.com

web: www.azden.com

When using two transmitters with the 330UPR please follow these important set-up instructions:

Frequency Selection-

Turn on one transmitter (35BT or 35HT or 35XT)

Change the number in the display window until it reads **30 - 01**

Turn on the second transmitter (35BT or 35HT or 35XT)

Change the number in the display window until it reads **30 – 11**

The first number **30** is considered the **GROUP** number.

The second numbers **01** and **11** are considered the **FREQUENCY** numbers.

The transmitters' should always be on the same GROUP number however the FREQUENCY numbers must always be separated by at least 10 spaces. Separating the channels by less than 10 spaces may result in interference.

Now follow the same set-up on the 330UPR receiver.

Turn ON CH1 and CH2.

Change the number in the display window until it reads 30 – 01

Next hit the button on the receiver marked **DISP ½**

(This button allows you to toggle between channel 1 and channel 2)

Change the number in display window until it reads 30 – 11

Now if it is set-up properly you should be able to hit the **DISP ½** button repeatedly and the numbers should change back and forth in the display from 30 – 01 to 30 – 11. If so, the frequencies are now set.

If you notice any interference using the above combinations please try different GROUP and FREQUENCY combinations. Such as: 31 – 01 and 31 – 11 or 32 – 01 and 32 – 11. The main point is to use the same GROUP number and always separate the FREQUENCIES by 10 or more spaces.

Proximity Effects:

When using two transmitters make sure they are both at least 10 feet away from the 330UPR.

This will prevent frequency overlapping which will result in noise and short working distance.

However, both transmitters will operate properly if they are in close proximity to each other.